



Model #: **PJ1S/W41**  
Model #: **PJ2S/W41**

Description: **Single Patient Station with Jack**  
Description: **Dual Patient Station with Jacks**

### Summary Description

The Single Patient Station With Jack Receptacle and the Double Patient Station With Jack Receptacles shall be wall recessed or surface mounted units designated PJ1S/W41 and PJ2S/W41 respectively, which shall provide facilities for their use with UL1069 listed call cords having 1/4-inch diameter plugs for routine patient bedside call placement. Units shall be provided with a combination call indicator and cancel switch with white lens stamped "CANCEL", and front panel replaceable lamp. Options shall include choice of lens colors and engraving of lens.

### Applications

The units shall be designed with standard 1/4-inch jack receptacles and indicator lamps on single faceplate for use as patient call placement for up to 2 beds. Units can be used in conjunction with standard UL1069 listed 2-conductor call cords with 1/4-inch diameter plug call cords, shower, toilet or bath emergency station(s), dome lamps, and centrally located visual display and alert tone annunciator panels.

### Signaling Operations

The units shall be designed to allow insertion and use of standard 2-conductor UL1069 listed call cords with 1/4-inch diameter plugs to initiate patient calls. Call placements shall illuminate the unit call indicator lamps, associated dome lamp, annunciator panel indicator and visual and tone display on duty stations. Removal of either patient call cord from its jack receptacle shall initiate a routine bedside patient call. Calls can be cancelled using the momentary CANCEL switch on the unit faceplate.

### Controls & Indicators

The unit shall be provided with the following controls and indicators:

- PJ1S/W41** One (1) standard 1/4-inch call cord receptacle for patient bedside call.  
One (1) momentary single pole, double throw front panel snap-in switch with white translucent lens stamped "CANCEL" in red letters, and a 28VDC 40 MilliAmperes wedge type indicator lamp under the switch actuator lens.
- PJ2S/W41** Two (2) standard 1/4-inch call cord receptacles for patient bedside calls.  
One (1) momentary single pole, double throw front panel snap-in switch with white translucent lens stamped "CANCEL" in red letters, and a 28VDC 40 MilliAmperes wedge type indicator lamp under the switch actuator lens.

### Options

The following options shall be made available:

- Choice of lens colors: White, Red, Green, Blue, and Yellow
- Choice of Clear lens with insert for identification marking
- Engraving of lenses with specified display information.
- Design for staff assist call upon removal of patient call cord
- Use of maintained action switch in lieu of momentary switch
- Choice of faceplate: White, Grey or Ivory molded ABS; Stainless steel

### Installation

Unit shall be provided with 6" long color-coded 22AWG stranded wires, stripped 1/2" for ease of installation and service.

### Housing & Finish

- Faceplate:** Standard 1-gang beveled edge molded grey ABS, supplied with non-conductive Nylon mounting screws.
- Housing:** 1-gang metal surface box finished in alumex
- Backbox:** 1-gang metal backbox

### Dimensions

- Faceplate:** 2-3/4" (6.99 cm) wide x 4-1/2" (11.43 cm) high x 1-7/8" (4.76 cm) deep
- S41 Housing:** 2-7/8" (7.30 cm) wide x 4-5/8" (11.75 cm) high x 2-1/4" (6.99 cm) deep
- W41 Backbox:** 4-11/16" (11.91 cm) square electrical backbox with 1-gang adapter for total depth of 2-3/8" (6.03 cm), supplied by others.

**VisiSTAT**<sup>®</sup>



Subject to change without notice. 060102

**VisiSTAT**<sup>®</sup> is a registered trademark of Ramex, Inc.