

Model #: **PJ2S/W42**

Description: **Dual Patient Station with Jacks (2-G)**

Summary Description

The Dual Patient Station With Jack Receptacles shall be a wall recessed or surface mounted unit designated PJ2S/W42, which shall provide facilities for its use with two standard 2-conductor UL1069 listed call cords having 1/4-inch diameter plugs for patient routine bedside call placement. Unit shall be provided with two individual combination call indicators and cancel switches with white lenses stamped "CANCEL", and front panel replaceable lamps. Unit options shall include selection of lens colors and engraving of lenses.

Applications

The unit shall be designed to provide two standard 1/4-inch jack receptacles and associated indicator lamps on single faceplate for use by up to two patients for bedside call placement and individual call indicators and associated cancel switches. Unit shall be designed for use in conjunction with up to two (2) standard 2-conductor UL1069 listed call cords with 1/4-inch diameter plugs, shower, toilet or bath emergency station(s), dome lamps, and centrally located visual display and alert tone annunciator panels.

Signaling Operations

The unit shall be designed to allow insertion and use of standard 2-conductor UL1069 listed call cords with 1/4-inch diameter plugs for patient use to initiate patient bedside calls to nurse. Call placements shall illuminate the respective patient call indicator lamps, associated dome lamps, annunciator panel indicators and visual and tone display on area or zone duty stations. Removal of either patient call cord from its jack receptacle shall initiate a routine bedside patient call. Calls can be cancelled using the respective momentary CANCEL switches on the unit faceplate.

Controls & Indicators

The unit shall be provided with the following controls and indicators:

- Two (2) standard 1/4-inch call cord receptacles for patient bedside calls.
- Removal of either patient call cord from its socket shall initiate a routine bedside patient call.
- Two (2) momentary single pole, double throw front panel snap-in switches with white translucent lenses stamped "CANCEL" in red letters, each with a 28VDC 40 MilliAmperes wedge type indicator lamp located under the actuator lenses.

Options

- The following options shall be made available:
- Choice of lens colors: White, Red, Green, Blue, and Yellow
- Choice of Clear lens with insert for identification marking
- Engraving of lenses with specified display information
- Design for staff assist call upon removal of either patient call cord
- Use of maintained action switches in lieu of momentary switches
- Choice of faceplate: White, Grey or Ivory molded ABS; Stainless steel

Installation

Unit shall be provided with 6" long color-coded 22AWG stranded wires, stripped 1/2" for ease of installation and service.

Housing & Finish

- Faceplate: Standard 2-gang beveled edge molded grey ABS, supplied with non-conductive mounting screws.
- Housing: 2-gang metal surface box finished in alumex
- Backbox: 2-gang metal backbox

Dimensions

- Faceplate: 4-9/16" (11.59 cm) wide x 4-1/2" (11.43 cm) high x 1-7/8" (4.76 cm) deep.
- S42 Housing: 4-3/4" (12.07 cm) wide x 4-3/4" (12.07 cm) high x 2-1/4" (6.99 cm) deep.
- W42 Backbox: 4-11/16" (11.91 cm) square electrical backbox with 2-gang adapter for a total depth of 2-7/8" (7.30 cm), supplied by others.

VisiSTAT[®]

